
## PHE L095X140SPACER



Size	95
Distance between shaft ends	140
Distance between shaft ends (in)	5.51

The contents of this publication are the copyright of the publisher and may not be reproduced (even extracts) unless prior written permission is granted. Every care has been taken to ensure the accuracy of the information contained in this publication but no liability can be accepted for any loss or damage whether direct, indirect or consequential arising out of the use of the information contained herein.

